



Technical Guide
Making and Playing Guide

If you are using a Windows PC, be sure to run Internet Explorer as an admin.

A screenshot of a Windows Start Menu search interface. At the top, there are three icons: a square with dots, a document, and a globe. To the right is a "Filters" dropdown with a downward arrow. Below these are two sections: "Best match" and "Search suggestions". In the "Best match" section, there is a result for "Internet Explorer" (Desktop app), which has a yellow and blue icon. A context menu is open over this result, with "Run as administrator" highlighted in gray. The menu also includes "Open file location", "Pin to Start", "Pin to taskbar", and "Uninstall". A horizontal line separates this from the "Search suggestions" section. The "Search suggestions" section shows a search icon followed by the text "ie - See web result". Below the search bar at the bottom are three small icons: a magnifying glass, a microphone, and a gear.

You can find/change the default file locations under the Local Configuration tab:

The screenshot shows the 'Local' configuration tab in a web-based video management system. On the left, a sidebar lists categories: System, Network, Video/Audio, Image, Event, Storage, and VCA. The 'Local' tab is selected. The main area contains three sections: 'Live View Parameters', 'Record File Settings', and 'Picture and Clip Settings'. In the 'Record File Settings' section, the 'Save record files to' field is set to 'C:\Users\SCWTech\Web\RecordFiles' and the 'Save downloaded files to' field is set to 'C:\Users\SCWTech\Web\DownloadFiles'. Both fields have 'Browse' buttons next to them. A red box highlights these two specific paths. At the bottom is a 'Save' button.

Once in the web interface, you can take a snapshot or make a recording in real time, from the Live View page.

The screenshot shows the 'Live View' page. At the top, there's a navigation bar with tabs for 'Live View' (which is active), 'Playback', 'Picture', and 'Configuration'. On the right, there's a PTZ control panel with buttons for pan, tilt, zoom, and Preset selection. Below the PTZ controls is a list of cameras: Sentinel Mini 2.0, Wasp Pro 3.0, FishEye, and Tracker Pro 2.0. The main area is a large video preview window. At the bottom of the preview window, there are several control buttons: a camera icon, a magnifying glass icon, a square icon, a circular icon, and other icons for brightness and contrast adjustment. A green circle highlights the camera icon at the bottom left of the preview window.


The Camera Icon takes a snapshot of the current live view and functions the same way from the playback menu.




Clicking the Camcorder icon will start manually recording the current camera's live view, click it again when you are ready end the recording.



From the Playback menu, the Scissors icon works the same as the Camcorder does. While playing the footage, click the Scissors once to start making a video clip and again to end the clip.



Using the Download function  **is useful for saving longer periods of footage or specific time frames.**



Search Conditions		File List					
Channel No.	File Type	No.	File Name	Start Time	End Time	File Size	Progress
IP Camera1	All Type	1	00000001397007201	2015-12-15 01:28:27	2015-12-15 01:28:42	2 MB	
		2	00000001397007301	2015-12-15 01:29:27	2015-12-15 01:29:43	2 MB	
		3	00000001397007401	2015-12-15 05:43:56	2015-12-15 05:44:15	4 MB	
		4	00000001397007501	2015-12-15 06:29:48	2015-12-15 06:30:26	7 MB	
		5	00000001397007601	2015-12-15 06:30:58	2015-12-15 06:31:24	5 MB	
		6	00000001397007701	2015-12-15 06:32:52	2015-12-15 06:33:09	3 MB	
		7	00000001397007801	2015-12-15 06:35:39	2015-12-15 06:36:05	5 MB	
		8	00000001397007901	2015-12-15 06:36:49	2015-12-15 06:37:06	3 MB	
		9	00000001397008001	2015-12-15 06:37:27	2015-12-15 06:37:40	2 MB	
		10	00000001397008101	2015-12-15 06:38:50	2015-12-15 06:39:14	5 MB	
		11	00000001397008201	2015-12-15 06:41:37	2015-12-15 06:42:02	4 MB	
		12	00000001397008301	2015-12-15 06:52:43	2015-12-15 06:53:03	3 MB	
		13	00000001397008401	2015-12-15 06:54:03	2015-12-15 06:54:25	4 MB	
		14	00000001397008501	2015-12-15 06:55:41	2015-12-15 06:56:02	3 MB	
		15	00000001397008601	2015-12-15 06:56:23	2015-12-15 06:56:45	3 MB	

Choose the dates you would like to download footage from and click search, this will display all of the files that make up that time frame. You can then select the files you need and click download.

To play back videos files you have made or downloaded, you will need to use our VSPlayer which you can download [here](#).